

Battery Test Systems
V7.0 Software Instruction Manual

Landt Instruments Inc

Jun 2019

Landt Instruments Inc

High Precision Battery Test Systems

2520 Vestal Parkway East #121

Vestal, NY 13850

Phone|Fax: (888)505-1296

Email: landt@landtinst.com

Website: www.landtinst.com

Table of Contents

| | |
|---|-----------|
| Introduction and Connection | 1 |
| 1.1 Introduction | 1 |
| Hardware Connection | 3 |
| The front and rear panel..... | 3 |
| Channel connection..... | 3 |
| Alligator clips..... | 3 |
| Connect to the computer | 5 |
| Software Introduction and Installation | 5 |
| Landt Monitor Software (LANDMon) | 6 |
| Start the software | 6 |
| Software features overview: | 7 |
| Start a test | 7 |
| Start a cycling test with the guide | 8 |
| Landt Testing Steps Editor software (LANDProc) | 10 |
| Classification of testing steps | 11 |
| Configure testing steps | 12 |
| Test Name Settings | 13 |
| Global Configuration Settings | 13 |
| Property Edit Settings | 15 |
| Addition and deletion of testing steps | 19 |
| Entity step settings | 20 |
| Prime Parameters Settings | 20 |

| | |
|---|-----------|
| End Conditions Settings..... | 21 |
| Log Conditions Settings..... | 23 |
| Similar objects parameter settings | 25 |
| Non-entity step settings | 26 |
| <i>Variables</i> | 26 |
| <i>Loop</i> 27 | |
| <i>Decision</i> 27 | |
| <i>Pause</i> 28 | |
| <i>Comment</i> | 29 |
| Safety Conditions Settings | 29 |
| Use of Variables | 31 |
| Loop Implementation | 32 |
| Some Using tips | 37 |
| | |
| Landt Data Processing Software (LANDdt) | 38 |
| Start the software | 38 |
| Software Features | 39 |
| Use of the software | 40 |
| | |
| Landt Calibration Tool Software (LANDCali) | 46 |
| Overview | 47 |
| Calibration Software operation: | 48 |
| Change the Box No. of the device | 50 |

Introduction and Connection

Introduction

Landt Battery Test Systems are designed for the test of a variety of primary and secondary batteries such as lithium-ion, nickel-metal hydride and nickel-cadmium batteries, from coin-cell batteries (0.001mA) to electric vehicle batteries (500A). The battery testers support battery tests in most cases, including materials research, battery life test, electric vehicle battery test. Our battery testers have been widely recognized by industrial battery manufacturers and university research groups for the high precision, high reliability and friendly interface.

The test system has the following features.

- **Each test system provides 1 - 8 independent channels.**

Landt CT2001 series battery test system comes with 1-8 independence channels. Several testing station can be connected and controlled by one computer at the same time. LANDT Battery Testing systems allow up to 10 testing devices (80 channels) to be controlled through one RS232/RS422 communication port in a computer. Each channel can be individually programmed to be constant-current charge and discharge, constant-voltage charge and constant-power discharge, constant-resistance discharge, OCV test (rest) etc.

- **Easy programming**

The LANDT Battery Testing systems come with a very friendly interface (Landt Monitor software) which allows users to start using it with little training, while the test procedure could be programmed to conduct complicated test.

1. It allows unlimited testing steps (more than 800) in a test;
2. The exit condition can be set by time, voltage, current, or a combination;

3. It supports self-defined Variables for very complicated cycle test.

- **Controllability**

Users can do "Jump (GOTO)" or modify the testing parameters during the test. Also it allows the stopped channels to get resumed (data monitor continues).

- **"Relocate Channel" function**

When the cell is moved from one channel to another, the testing can be resumed with data collection continued.

- **Support the auxiliary test channel**

While users are doing the regular charge/discharge testing, auxiliary test channel can be used to test temperature, pressure, single cell voltage at the same time. This greatly expands the test capability.

- **Effective data backup**

The software supports automatic data backup during the test.

- **Powerful data processing capability**


The Landt Data Processing software is small but powerful. The detail will be discussed.

- **Reliable and efficient connection**

The software can control many Landt battery testers at the same time. Each test device has two serial ports which allow all the boxes to be connected one by one. The last device is connected to the serial port interface of the computer.


Hardware Connection

The front and rear panel



(Figure 0-1)

Channel connection



- ① Connect to positive electrode, Voltage measurement;
- ② Connect to positive electrode, Current path;
- ③ Connect to negative electrode, Current path;
- ④ Connect to negative electrode, Voltage measurement.

(Figure 0-2)

Alligator clips

Each set of the alligator clips contain four clips: big red clip, big black clip, small red clip and small black clip. Please note:




Figure 0-3

Red clips connect to positive electrode of the battery;

Black clips connect to negative electrode,


with

Big clips to supply/monitor the current;

Small clips supply/monitor the cell voltage.

For connection of three-electrode test the big red clip connects to positive electrode of the cell while big black one connects to the negative since the big alligator clips help forming the current loop. Small red clip and small black clip are to measure the cell voltage, so they should be connected to the working electrode and reference electrode respectively.

Connect to the computer



Landt Battery Testing systems use RS232/RS422 serial port (9-pin port) to communicate with the computer. To make the connection, use the communication cable (provided with the test system) to connect the RS422 port on the back of the test machine (Figure 1-1 ⑦ or ⑧) to a serial port on the desktop computer. If there are several tester units, use the other RS422 port (⑦ or ⑧) connecting the next unit and thus all the units can be connected in series. The computer automatically searches for all the tester units.

If a PCI-e to serial port adapter card is installed on the computer, make sure the driver is also updated. The user can also use a USB to RS232 serial port converter. It is strongly suggested using a serial port on the desktop since the communication is more reliable.

Software Introduction and Installation

The Landt Battery Testing system software includes four parts, Landt Monitor Software (LANDMon), Landt Testing Steps Editor software (LANDProc), Landt Data Processing Software (LANDdt) and Landt Calibration Tool Software (LANDCali). The latest software can be downloaded from manufacturer's website.

Landt Monitor Software (LANDMon)

It is assumed that the users are familiar with Windows operation system and the use of the mouse and keyboard. In the following "left click" means click the left button of the mouse, and "right click" click the right button of the mouse.

Start the software

Before starting the software, the battery testers should be plugged in with power supply and switched on. Make sure all testers are connected in series and connected with the computer via serial ports.

Double click the shortcut icon "LANDMon" to start the Data Monitor Software. "LANDMon" starts with the interface shown below. If 8 channels are shown in the window, the connection is successful. 001, 002 and 003 etc. indicate different device boxes. In the following figure there are four boxes (32 channels) connected to a computer.




Figure 0-1

If the power was not turned on before starting software, or the communication port was not connected to the computer serial port, you can set them down and then select menu "Network">"Connect" to re-start the automatic connection process.

Software features overview:

The software for Landt Battery Testing systems have the following features. Most of them can be achieved by right click the channel.

- 1) Automatic test. The test is fully automatic and controlled by the computer. Before the test working steps needs to be scheduled. A schedule normally contains many steps and sometimes cycle loops.
- 2) Real-time monitor. It displays charge and discharge status (including voltage, current, capacity, number of cycles, etc.) during the test.
- 3) Channel start. Every channel is independently controlled. So they have to be scheduled and started manually, although the schedule can be saved and re-loaded, and several channels can be started at the same time if they use the same schedule.
- 4) Channel stop. A channel automatically stops after completion of all the steps. At the same time, the software also allows the user to stop it manually.
- 5) Jump. During the test the user can manually suspend the current step and jump to a specific step.
- 6) Setup parameters modification. Parameters in the schedule can be modified during the test.
- 7) Channel resume. After stop the channels can be resumed and data sampling will continue. It will follow the schedule which was programmed last time.
- 8) Active materials loading. The active loading is used to calculate specific capacity.
- 9) Real-time monitor of the data. The data can be opened at any time during the test.

Start a test

Landt battery tester allows users to set unlimited steps in a single test in each channel. In each step it can be set as CCC (Constant Current Charge), CVC (Constant Voltage Charge), CCD (Constant Current Discharge), Rest, DCIR and so on. In addition, *Loop* and *Decision* can be used to implement cycle or specific jumps. The user can also set self-defined Variables to set up the cycles. All these operations will be fully discussed, however, new users are strongly recommended to use the guide to set up the test.

Start a cycling test with the guide

Open the Landt Monitor window, chose the menu "Test">"Start a Test", you'll see the test table (Figure 0-2). The table shows the previously-used test schedules in the list in case the user wants to use or modify one of them. Choose "New" to set up a new test in the new window.




Figure 0-2

Users can also right click the channel and select "Start". Click the test name to schedule a program. In the dialog box data backup plan can be scheduled. We can set the backup directory and the name of the test data. The name is set as "AB_C.cex" where for example B stands for the unit number (box number), C is the channel number. If A is not checked the data will be saved as for example "_001_2", which stands for Channel 2 in unit 001.




Figure 0-3

Click on the testing name (Figure 2-3), or double click the "LANDProc" icon on the computer desktop----You can start the Testing Steps Editor software (LANDProc.exe).

Complete the step editing settings in the Testing Steps Editor software (LANDProc.exe). After the setup is done right click the channel and select "Start" to start the test.

Landt Testing Steps Editor software (LANDProc)

In this section, the parameters in the Testing Steps Editor software are introduced.




Figure 3-1

The software uses flow chart to edit working steps. For simple tests, the writing of flow chart is simple and clear. Using the software to write test steps, it can be understood almost at a glance, even without reading the other document.

As can be seen from Figure 3-1, the main interface of the software (LANDProc.exe) consists of menu bar, working step object bar, common toolbar, status bar and editing area, while the editing area includes three parts: flow chart editing area, test name and global configuration.

Classification of testing steps (working mode)

The default Testing Steps Editor software includes *CCC*, *CCD*, *CVC*, *CC-Rate*, *DCIR*, *Rest*, *Loop* and *Decision*, *Pause* and so on. Users can also add other working steps that need to be enabled by choosing the main menu command "Options > Config Steps".

| Icon | Meaning | Type |
|---|---|------------------|
|  CCC | Constant Current Charge | Entity Steps |
|  CCD | Constant Current Discharge | |
|  CVC | Constant Voltage Charge | |
|  CVD | Constant Voltage Discharge (not yet realized now) | |
|  CC-Rate | Charge at constant current Rate | |
|  DC-Rate | Discharge at constant current Rate | |
|  CPC | Constant Power Charge | |
|  CPD | Constant Power Discharge | |
|  CRD | Constant Resistant Discharge | |
|  Rest | Rest | |
|  DCIR | Direct Current Internal Resistance | |
|  Variables | Variables | Non-entity Steps |
|  Loop | Loop | |
|  Decision | Decision | |
|  Pause | Pause | |
|  Comment | Comment | |

The testing steps can be divided into two groups: entity step and non-entity step.

1) Entity step: refers to the step that can be directly assigned to the test channel as the charging, discharging or other working state. For example: *Rest*, *CCC*, *CVC*, *CCD* and so on.

2) Non-entity step: the step that can't be given to the test channel as a charge or discharge state is non-entity step. For example, *Loop*, *Pause* and *Decision* and so on. Non-entity step usually plays the role of process control or as a specific program marker, which

enhances the performance of test programming and makes test programming simple and flexible.

The first "testing step" is usually set to *Rest*, and the sampling voltage (or display voltage) is the open circuit voltage (OCV) of the battery under test.

Configure testing steps

Select the main menu command "Options > Config Steps" and pop up the " Config Steps" window (Figure3-2), where each work step bar currently has a selection flag (check button). When the selected flag is the selected state, the corresponding working step is enabled; otherwise, when the selected flag is unselected, the corresponding working step is not enabled.

Users can select the testing steps to be enabled according to their needs, select "Hide disable steps" and click the "OK" button, then the working step selected by users will be displayed in the working step object bar, and the working step not enabled will be hidden (will not be displayed in the working step object bar). Through the settings of this window, users can add or hide working steps in the object bar at any time.




Figure 3-2

Test Name Settings

Double-click the "Unnamed" display box on the main interface of testing steps editor software, and pop up the test name "Parameters" setting window (Figure 3-3). The "Testing Name" can be set by the user.




Figure 3-3

Global Configuration Settings

Double-click the "Global Configuration" display box in the main interface of Testing Steps Editor, and pop up the "Parameters" settings window of Global Configuration (Figure 3-4). The "Global Configuration" includes detailed parameter settings of "Unit Scheme", "Voltage Safety", "Current Safety", "Capacity Safety" and "Change-trend Safety".

◆Unit Scheme Settings: Click on the "Details" button on the right side of the Unit Scheme Settings Bar (Figure 3-4). It shows "Unit Scheme" Settings Window (Figure 3-5). At present, there are three unit schemes: "based on mA", "based on Ampere" and "based on uA". Users can choose according to the test requirements. At present, the software only supports changing the unit scheme for current, while the voltage unit is fixed at Volt. The corresponding capacity, power, resistance and other boxes will change according to the change of current unit.




Figure 3-4




Figure 3-5

◆ Voltage Safety setting: As shown in Figure 3-4 above, one of the "Voltage Safety" is "overvoltage range protection", which means that when the voltage is measured, the measured value of the voltage reaches 101.5% of the rated voltage of the test battery (that

is, the measured value of the voltage). When the battery voltage exceeds 1.5% of the rated voltage, "Voltage Safety" will take effect and the test will stop.

The last item in "Voltage Safety" is a time to set the voltage protection delay to take effect. This is mainly used in some cases when the battery is in the initial low-voltage state (for example, before the battery formation), and it takes a short charge to enter the normal voltage range. The "Voltage Safety" does not work at the beginning. It only takes effect when the battery enters the normal state.

◆Current Safety setting: The last item in "Current Safety" is "super current range protection". It is mainly used for charging state. The measured value of current reaches 101.5% of the rated current of the test battery (that is, the measured value of current exceeds 1.5% of the rated current of the battery). Then "Current Safety" comes into effect and the test stops.

◆Capacity Safety setting: When the capacity value accumulated by the battery exceeds the charging capacity setting value during continuous charging, or when the capacity value accumulated by the battery during continuous discharging is lower than the discharge capacity setting value, the test stops.

Detailed settings for protection conditions (including "Voltage Safety", "Current Safety", and "Capacity Safety") are provided in the following sections.

Property Edit Settings

Click on the small settings button  on the right side of any Step Parameter window and enter the Property Editing Settings dialog box (Figure 3-6).

In the "Prop Edit Set" interface, there are four kinds of attribute settings: "Input conditions", "Input confirm", "Independent safety protect for steps", and "Limit-parameters for steps". The "Input confirm" only involves the selection of confirmation shortcut keys, which is simple and easy to understand. There is no further explanation here.




Figure 3-6

1. Input conditions

When "Input conditions" chooses "The classical method", the mouse clicks the edit box of "End Conditions" and it comes the "Multi-Conditions Edit" dialog box (Figure 3-7). As can be seen from the figure, the interface of "Multi-conditions edit" is similar to that of the old version of testing step editing. The function of "The classical method" is mainly to take into account the users' habits of the old version software.




Figure 3-7

As shown in Figure 3-7, in the Multi-Conditions Edit window, the "+" or "-" keys are used to add or reduce conditions to form single or multiple conditions.

When "Input conditions" chooses "Text with syntax high lightening", the mouse clicks on the edit box of "End Conditions", then the user's set conditions will be highlighted in the form of yellow rectangular box above the edit box (Figure 3-8).




Figure 3-8

2. Independent safety protect for steps

When the "Independent safety protect for steps" are selected as "Enable All" or "Enable, except Rest", the "Safety Conditions" edit box in the main interface of "parameters" will be available (Figure 3-9). Users can set different security protection conditions for each step according to the test requirements. The setting step and function of "Independent safety protect for steps" are consistent with the protection conditions of the working step. Please refer to the following chapters for details.




Figure 3-9

The "Safety Conditions" edit box will be disabled when the "Independent safety protect for steps" is selected as "Disable" (Figure 3-10). For the testing process, only the security parameters set in the "Global configuration" can play a protective role.




Figure 3-10

3. Limit-Parameters for steps

When "Limit-Parameters for steps" is selected as "Enable", the "Lmt-Para for steps" edit box in the main interface of "Prime Parameters" will be available (Figure3-11). Enable and set the "Limit Parameters" to play the role of current limiting protection for the current charging process.




Figure 3-11

When "Limit-Parameters for steps" is selected "Disable", the "Lmt-Para for steps" edit box in the main interface of "Prime Parameters" will be disabled, and the "Limit-Parameters for steps" function is invalid(Figure3-12).




Figure 3-12

Addition and deletion of testing steps

Adding a step: directly click on the step object, and drag it to the flow chart area to edit the step. The step will be automatically added between "test begin" and "test end".

The software allows the user to click the right mouse button and use the pop-up menu to delete, copy, cut or paste the steps (Figure 3-13).

Delete: right click the mouse to get the menu "Delete" or press the < Delete > key to delete the currently selected step.

Copy or cut: refers to the current selection of the step to copy or cut.

Paste before this object: refers to pasting and inserting the current copy or cut step into the previous step of the current step.

Selection of all similar objects: refers to the selection of all the same steps as the current step-mode in a complete test process. For example, the current selected step is "constant current discharge". After clicking "select all similar objects", all the "constant current discharge" steps will be selected in the test process.

When the mouse clicks on any step, a red rectangular box appears around the step, indicating that the step is being selected. At the same time, there will be a red number in front of the left of the step, representing the step number in the flow chart, which is automatically generated by the software and can't be edited.

The *Loop* or *Decision* step always contains an arrow to go to another step which can be set, by either enter the value or by drag the arrow.




Figure 3-13

Entity step settings

Prime Parameters

After adding steps to the flow chart area, you need to set the parameters for the steps in detail (Figure 3-14).




Figure 3-14

Double-click a step to bring up the Detailed Parameters dialog box. In this interface, you can set the "Prime Parameters", "End Conditions", "Log Conditions", and "Safety Conditions" of the step. The user can arbitrarily perform "main parameter setting" under the premise of obeying the agreed syntax format.

End Conditions Settings

In the "End Conditions" edit box, click the black triangle icon to the right of the edit box to bring up a floating menu (Figure 3-15).




Figure 3-15

Support for "step time", "voltage", "current", "capacity", "-DV", "charge and discharge cycle", "DC internal resistance", user-defined variable, "current" in the end condition Real-time variables such as "magnification" and "coulomb efficiency" are compared for "=" (ie, "→"), "≥", "≤", ">", or "<" relationship.

The end condition may be a simple single condition, or a complex condition group consisting of multiple conditions by "or" and "and" mixing operations.

If you need to change or delete an end condition that has been set, click the "End Condition" edit box and click <Delete> to delete, then re-edit.

The "Step Time" item accepts a common time format in addition to accepting an integer second value. For example, "30:10" means 30 minutes and 10 seconds, "1:30:00" means 1 hour and a half, and so on.


Here: "step time" refers to the time when the current step has been executed; "voltage" and "current" refer to the voltage and current values sampled in real time; "capacity" refers to the cumulative capacity of continuous or continuous discharge (possibly several working steps) "-DV" means $-\Delta V$, which is the negative slope; "charge and discharge cycle" refers to the number of cycles displayed to the user in the test window of the monitoring software (LANDMon.exe) -- that is, the number of times the charge and discharge are converted. It is globally accumulated; "t1", "C1", "N1", and "N2" are custom variables.

The software does not have any restrictions on the use of the above variants. For example, when charging a constant current, the "current" variable can be compared - in fact, even if the test equipment and the battery are normal, if the fixture is open, the actual output current cannot be guaranteed. Equal to the set current value - thus, in some special cases, this comparison is also meaningful.

The end condition fills in nothing, the default is "TRUE". It can also be understood that if the user does not fill in an end condition, it is unconditionally terminated, that is, the end condition is always satisfied. If a "working step" includes multiple end condition groups, the previous condition group is checked first.

Log Conditions Settings

In the entity step of operation, the detailed parameter settings also include the Log Conditions (Figure 3-14). The recording condition defines the frequency of data recording during the test. It includes three items: "Dlt-Time", "Dlt-Voltage" and "Dlt-Current". The meanings are: how long the interval records a data; when the voltage changes, A data is recorded when the voltage is raised or lowered by how many volts; when the current changes, how much mA is increased or decreased when the current is recorded.



The screenshot shows a window titled "Parameters" with a close button (X) in the top right corner. The window is divided into several sections:

- Prime Parameters:**
 - Mode: CCC (dropdown menu)
 - Main Para: 0 mA (text input)
 - Limit Para: (empty text input)
- End Conditions:**
 - Time ~ 05:00 (text input)
- Log Conditions:**
 - Dlt-Time: 10 Sec (checkbox and text input)
 - Dlt-Voltage: (empty text input) V (checkbox and text input)
 - Dlt-Current: (empty text input) mA (checkbox and text input)
- Safety Conditions:** (empty section with a plus icon)

Figure 3-15

In the Log Conditions, each item has a selection mark (i.e., a check button) in front of it: when the selected mark is selected, the item is valid; otherwise, it is invalid, even if the user has entered a value in the corresponding line edit box, ignored by the software -- in fact, as long as the user enters the value in the edit box, the selection mark at the beginning of the line automatically changes to the selected state unless the user forcibly changes it.

The above three items are logical "OR" relationships, that is, if any one condition is satisfied, one point will be recorded. Among them, "Dlt-Time" item accepts a commonly used time format, such as "00:2:10" or "2:10", in addition to accepting an integer second or millisecond value, when the selected unit is seconds, which means 2 minutes and 10 seconds.

It is important to note that recording conditions define how to record data points, which should be as finely as possible in order not to lose the main features of the test. It does not affect the accuracy of some parameters that is calculated by the software. In real time test—because of real-time sampling It's always in progress, it's not controlled by the user, and the data points that the user records are saved are only a small fraction of the many sample points. For example, capacity----it is the integration of real-time current value over time, independent of user-defined recording conditions.

So, how do you set the specific values of each item in the recording condition? According to experience, usually a complete cycle has no less than 80-100 record points, and the curve is relatively smooth. "Time variation" can be used to ensure the minimum number of recorded points. Considering "voltage change" or "current change", some recording points are added, and the value can be taken as $1/80$ -- $1/50$ of the cycle period, for example, 0.5C charge and discharge, one cycle is 4h (charge and discharge for 2h each), considering that the current in the constant voltage phase is small, and there will be a certain overcharge during charging (reasonable overcharge), take a cycle of 5h, count $5 \times 60=300$ Min., the "Dlt-Time" value can be set to $300 \times (1/80-1/50) \approx 4-6$ Min.; using "voltage change" or "current change" to ensure the recording of feature points. The value can be taken as about 1% of the full scale of the device (of course, also refer to the normal voltage and current range of the battery under test), for example, the range is 5V, and the "Dlt-Voltage" can be set to 0.04 - 0.05V. Of course, the software supports users to adjust the values of various parameters in a wide range, and users can completely set their own standards according to their actual needs and experience.

Similar objects parameter settings

The Landt Testing Steps editor software can simultaneously set parameters for the same kind of objects (IE the same working mode) in a test process. In a complicated charging and discharging test process, for a plurality of testing steps having the same working mode and working parameters, the function of simultaneously setting parameters eliminates the cumbersome operation of setting one step of the working step parameters. Save time for step editing.

Right click on the blank area of the editing area, pop up the right-click menu item (Figure 3-16), click the "Select All Charging Objects" or "Select All Discharging Objects" menu to select the same kind of objects.




Figure 3-16

Right click on an entity working step to get a context menu (Figure 3-17). Click "Select All Similar Objects" to select all the similar steps in the flow chart, and then right click to choose "Properties". In this way two or more identical working steps can be set or modified at the same time.




Figure 3-17

Non-entity step settings

Variables

Variables are mainly used to program very complicate tests. Custom Variables currently support Time Variable t1, Capacity Variable C1, and Counter Variables N1 and N2. Custom variants can be used in "End Conditions". Variables of each channel do not affect each other and are completely independent in each channel.

Drag the "Variables" into the flow chart and double-click to get the Detailed Parameters window (Figure 3-18). Each Variables setting bar currently has a selection flag (check button). When the selected flag is selected, the corresponding Variables operation is valid; otherwise, the corresponding Variables will not execute if not checked. Multiple entries can be selected at the same time. A quick way is to use the space key: first select one line, press the space key, then it goes to check or uncheck the next one.




Figure 3-18

"0->t1" means reset t1 (t1=00:00:00). "0 ->N1" means reset N1(N1=0), "N1+1->N1" means N1 gets increased by 1, and other entries are analogous.

Time Variables t1: The software automatically performs time accumulation by itself, and needs to perform "0->t1" operation first.

Capacity Variables C1: Similar to t1, the software automatically performs capacity accumulation by itself, and needs to perform "0->C1" operation first.

Counter Variables N1/N2: No automatic operation is performed on these two variables by the software. The operation is completely dependent on the setting in the flow chart. They need to be reset in a step (N1=0 or N2=0), and run "N1+1->N1" or "N2+1->N2" operation in a proper position (another step). They are independent but work exactly the same way.

Loop

Loop is used to run cycling test of batteries. Parameters of the *Loop* step includes cycle number (Loop Times) and "Loop From Step". (Figure 3-19). "Loop From Step" refers to the step to which the test goes back. It can be set by either dragging the red arrow or inputting the step number in the parameter window. The software does the accumulation of cycle number by itself and determine if Loop Time (cycle number) is met or not. If not, it goes back to a previous step.

Support 3-level nested loops.




Figure 3-19

Decision

Decision enables the test goes a specified step if some condition is met. Parameters of the *Decision* step consist of "Goto Conditions" and "Goto Step" (Figure 3-20). The "Goto Conditions" setting is the same as the end condition setting. It can be time, voltage, current, cycle, etc. If "cycle" is chosen, it does the same job as "Loop".

The role of *Decision* is to perform jump condition judgement and jump to a specified step. Since the *Decision* is a non-entity step, and the test won't stay in the step. If the "Goto Condition" is not met it will go to the next step.




Figure 3-20

Pause

The *Pause* step has no parameter setting and can only add some prompt text (Figure 3-21). *Pause* means that the test is suspended and held at the "step".

The difference between *Pause* and *Rest* is that *Pause* step means to suspend the test. *Pause* step will not charge or discharge the battery. The test will not go to the "next step" by itself. *Rest* step can be regarded OCV test. It is either constant current charging or constant current charging, with current value at approximates zero. *Rest* can define the end conditions. If it meets the end conditions, the test automatically to "next step".




Figure 3-21

Comment

"*Comment*" is used to take notes or input some information in the blank area next to the flow chart (Figure 3-22).




Figure 3-22

Safety Conditions Settings

Double-click the "Global Configuration" in the main interface of the software, and it shows a parameters setting window (Figure 3-23). Among them, "Voltage Safety", "Current Safety", "Capacity Safety" and "Change-Trend Safety" are all safety conditions in the test. "Assistant Channel Safety" refers to auxiliary channels. Normally it is not enabled.




Figure 3-23

"Safety Conditions" is to assure battery tests running within normal voltage/current ranges. It works only when something unusual happens and the cell voltage/current goes beyond normal range during the test. For example, unreasonable parameters are set for the test and there is no end condition. In some case the battery cell itself has problems. During the test if "Safety Conditions" is touched, the test will stop. When the abnormal condition is removed, the test can be resumed with "continue" function.

Commonly used protection is voltage protection. Lithium-ion batteries seldom go beyond 5V. Nickel-cadmium and nickel-hydrogen battery are seldom discharged to 0.6V or below, nor are charged to 1.6 V or higher. The item in "Delay Check Voltage" works at the beginning of some tests when the initial cell voltage is ridiculously low while charged

it comes into normal range. For example, some lithium cells may have the OCV of 0V before formation, but after an initial charge the cell voltage will come to normal.

Use of Variables

1. Time Variables t1: The software automatically performs time accumulation by itself since the reset operation (0->t1).

Figure 3-24 is an example of using a time Variables t1. The test achieves a special feature: cell voltage is maintained between 4.0V and 4.2V for 48 hours. Here t1 is used as a timer.




Figure 3-24

2. Capacity Variables C1: similar to t1, the software automatically performs capacity accumulation during charge/discharge by itself since the reset of C1 (0->C1).

Figure 3-25 shows an example of capacity Variables C1 that in a cycle test (500 cycles) the capacity for constant voltage charge must be less than 800 mAh, otherwise the test will terminate.




Figure 3-25

3. Counter Variables N1/N2: different from t1 and C1, there is no accumulation by the software unless instructed. They need to be set (0->N1 or 0->N2) and in a proper step to run (N+1->N, N get increased by 1). Use of Variables N1/N2 is described in the next section “Loop”.

Loop

1. using a "charge and discharge cycle" to achieve a simple cycle

The "charge and discharge cycle" refers to the number of cycles displayed to the user in the test window of the monitoring software (LANDMon.exe)—that is, the number of times the charge and discharge are converted. The user can monitor it in the "End Conditions" and *Decision*. The "charge and discharge cycle" is an internal real-time variable whose initialization and accumulation are automatically done by the software.




Figure 3-26

Figure 3-26 is an example of a simple 50-cycle with a "charge and discharge loop "Variables.

It should be specially pointed out that: 1 The accumulation of the "charge and discharge cycle "Variables needs to have alternating changes of charge and discharge. If there is only charge or only discharge, the value of the "charge and discharge cycle" Variables does not change; 2 "charge and discharge cycle" The Variables is initialized only once when the channel is initially started (automatically by the software), and is always accumulated during channel operation—that is, it is Global.




Figure 3-27

The example in Figure 3-27 is a misuse of the "charge and discharge cycle" Variables. The original purpose of the test was to perform 20 cycles with a 5 mA current followed by 30 cycles with a 2 mA current. In fact, only 10 cycles are performed with a current of 2 mA, because after 20 cycles with a current of 5 mA, the "charge and discharge cycle" Variables has been accumulated to 20, and only 10 cycles are required to reach 30 cycles. In this case, using the custom VariablesN1/N2 is not easy to make mistakes and is easy to understand (see below).

2. using the custom Variables N1/N2 to achieve a simple loop

The counters N1/N2 are used for counting, and their operation is completely dependent on user control (including clear operation and add 1 operation). Counter N2 is used in exactly the same way as counter N1.




Figure 3-28

Figure 3-28 is an example of a loop implemented using the custom Variables N1. It also demonstrates the case where a custom variable is used multiple times in the same test. It implements this test: first charge and discharge 20 times with 5mA current. After the cycle, 30 cycles were followed by a 2 mA current.

3 Use the custom Variables N1 and N2 to achieve complex nested loop

Figure 3-29 shows an example of nested loop using custom counter the variable N1 and N2.




Figure 3-29

In Figure 3-29, steps 4 to 12 are large loop bodies, and steps 5 to 8 are inline small loop bodies. It implements such a test process: firstly charging and discharging 5 cycles with a small current of 6 mA, and then charging and discharging one cycle with a large current of 10 mA, and repeating 10 times in this manner.

Tips

1. Support "Undo/Redo"; Support "Copy/Paste between documents".
2. Support selecting multiple steps and rewrite their parameters at the same time.
3. Easily operable loop programming; Support 3-level nested loops; Support 5-level nested loops in cooperation with the variable N1/N2.
4. Condition expression: text with syntax highlighting; meanwhile support the classic method (V5.9); And also can use auto-comparison symbol "~".
5. Flexible multi-select by using the mouse with <shift> and <Ctrl> key; Support "Clone and Drag" by pressing <Ctrl> key
6. Support scrolling the mouse wheel forward/backward to zoom in and zoom out the curve. (Also supported: <Ctrl> + '+' or <Ctrl> + '-' key)

Landt Data Processing Software (LANDdt)

Start the software

Double click "LANDdt" icon or select the "Open Data" in the control software (LANDMon), you can also start the data processing software.




Figure 4-1

As can be seen from the figure:

- Multiple (test) data files can be opened in the same window
- The window contains graph on the left and data on the right.

Software Features

Data Analysis

1) Analyze data in different format. This includes data entry show/hide, display cycle range, fold and expand the cycle data, fold and expand detailed data.

2) Copy the data to Windows clipboard

3) Data export

4) Set discharge plateau

5) Set active material parameters and cycle

6) View test Information: view channel information and setting up information;

7) Check test event: View other information during the test (such as power-down, safety alert and stop, etc.) or the user's operation (such as mandatory jump, stops)

8) Data printing and print preview

a) Graph operation

1) Graph settings: Set the drawing for corresponding data (such as voltage - discharge capacity graph, Efficiency - Cyclograph etc.).

2) Viewing graphs: including moving graph, zoom in or out, etc.

3) Copied to the WINDOWS clipboard.

4) Graphic axes: Setting the axis range, re-scale, grid lines and axes caption etc.

5) Units: Setting the unit for the axis.

6) Cycle data comparison: Put several cycling data in the same graph.

7) Graphic printing and print preview.

Use of the software

In the following windows a test data file is opened. The data area is on the right, while the graph is shown on the left. After right click the index header bar, a menu will pop up; which allows what kind of data rows to be shown in the data area. Right click in the data table another menu will also pop up, where there are many other selections (Figure 4-3).




Figure 4-2




Figure 4-3

Typically, a complete test consisted of many (charge/discharge) cycles, in which each cycle includes several steps (charge, rest and discharge), and each step also includes a many data recorded (time, voltage, current etc.). Thus, the data is divided into cycle data, step data and detailed recorded data. To view these data in detail, the user can just click **[+]** to unfold and **[-]** to fold the data.

Please note that when a row of data is selected (by left click the mouse), the index header bar automatically changes for cycle data, step data or detailed recorded data. This facilitates users to copy the data they need.

For cycle data

| Index | Charge-Cap/mAh | Disch-Cap/mAh | Efficiency/% | Mid_Volt/V | CC-Percent/% | FlatD/% | FlatDTime | CapKeepD/% | DCIR_D/mOhm |
|-------|----------------|---------------|--------------|------------|--------------|---------|-----------|------------|-------------|
|-------|----------------|---------------|--------------|------------|--------------|---------|-----------|------------|-------------|

For step data

| Index | Mode | Period | Capacity/mAh | GmCapacity/mAh/g | Power/mWh | Capacitance/F | SEnergy/Wh/kg | Mid_Volt/V |
|-------|------|--------|--------------|------------------|-----------|---------------|---------------|------------|
|-------|------|--------|--------------|------------------|-----------|---------------|---------------|------------|



For detail recorded data

| Index | TestTime | StepTime | Current/mA | Capacity/mAh | Voltage/V | Energy/mWh | SysTime |
|-------|----------|----------|------------|--------------|-----------|------------|---------|
|-------|----------|----------|------------|--------------|-----------|------------|---------|

The data which is inconsistent with the header bar (not the same level) is displayed as grey.

A) Set the cycle range to be displayed

In the "Data Selection Browse", click the small box on the right. In the dialog box the cycle range can be set. If the "Data Selection Browse" is not shown in the window, make sure in the top menu "View">"Data Selection Pane" is checked.



B) Fold/unfold the data

The first method is to directly left click the fold icon. If the data is folded (corresponding to the cyclic data is not visible), left-click the "[+]" icon, the corresponding data will become visible. Similarly, click on the "[-]" icon to fold the corresponding data.

Users can also use the  icons to fold and unfold the data.

C) Copy the data to WINDOWS Clipboard:

Select data:

First fold or unfold to view the data. Click one row of the data then the header bar will change accordingly. Select in the header bar the columns you want to copy. The background of the columns will become black. Right click the mouse, select "Copy the data" which can be directly pasted in Excel or Origin. It should be noted that during the copying "What You See Is What You Get (WYGIWYS)" those data which is invisible (folded) is not copied.




Figure 4-4

D) Active material parameters

The screenshot shows the "Active Material" dialog box. It contains the following fields and options:

- Active Material: 1800.0001 mg
- Nominal GmCap: (empty) mAh/g
- Cycle Definition:
 - Normal Mode: A cycle start on charge, then discharge.
 - Reverse Mode: A cycle start on discharge, then charge.
- Buttons: OK, Cancel

Figure 4-5

Right click the data table and select "Active Material" the weight of the active material can be set. Based on it Specific Capacity (mAh/g) (Charge-SpeCap and Discharge-SpeCap in the header bar) can be calculated.

For some cells it needs to discharge first before charge in a cycle, especially for anode materials research with a half cell (Graphite-Li, Si-Li), it can be set here whether a cycle starts from charge or discharge.

E) View test Information. The test information can be viewed which contains the initial setup for the test.




Figure 4-6

F) Check test event. It's to view test event during the test (such as power-down, safety issue, etc.) or the user's mandatory operations (such as mandatory jumps, stops).




Figure 4-7

Landt Calibration Tool Software (LANDCali)

Three basic parameters of Calibration: time, current, and voltage are involved in the battery test systems. All the other values are calculated based on the three basic parameters. "Time" is defined by the computer (PC) systems, which has little to do with the test equipment. Thus, the basic calibration parameters only contain the current and voltage.

There are three important values in the test system, which are used to evaluate the precision of the test system: the set value which is set by the user, the measured value which is the actual output from the device and the displayed value. Due to inevitable problems, the closer of the three current values, the better the precision of the test machine. Here, we use control inaccuracy to represent the difference between the measured value and the set value, measurement inaccuracy to represent the difference between the displayed value and the measured value.

Assuming current control inaccuracy: 0.1% RD +0.1% FS. That is to say:

Control inaccuracy = $|\text{set value} - \text{measured value}| \leq \text{set value} \times 0.1\% + \text{current range of the equipment} \times 0.1\%$

Similarly, if the current measurement: 0.1% RD +0.1% FS. That is to say:

Measurement inaccuracy = $|\text{measured value} - \text{the display value}| \leq \text{measured value} \times 0.1\% + \text{current range of the equipment} \times 0.1\%$

The 4 electrodes are used in the calibration. All battery test channels have four electrodes which contain two current output leads and two voltage measurement leads. In the following picture it shows the four leads. From the color and size of the alligator clips the leads can be identified: big clips for current output/input, little clips for voltage measurement, red clip connecting the positive electrode of a battery, black clip connecting the negative.

Overview

Typically, after prolonged use of electronic instruments it may result in reduced accuracy. The battery test system supports accuracy correction through the online precision adjustment. To calibrate the test system, the user doesn't need to open the "box". The user can even calibrate some channels while the other channels are still testing since all the channels are independent. The calibration is performed through the calibration software (LANDCali.exe).

Manual calibration: a multimeter is needed.

The precision calibration tool (LANDCali.exe) itself is an independent software. It is recommended that LANDMon/LANDCore is closed during the calibration, since some other functions may be restricted.

For current calibration

Connect the multimeter as indicated in the following figure.




Figure 5-1

Note only BIG alligator clips are used for current calibration. SMALL clips for voltage measurement are not involved.

For Voltage calibration




Figure 5-2

As shown above, all the four clips are used in the voltage calibration. Note please DO NOT let small clips and big clips touch (small red and big red, small black and big black), otherwise the calibration will be affected.

Calibration Software Operation:

1. Connect the device with the computer.
Start the LANDCali software.




Figure 5-3

Press "Connect", the LANDCali will search for devices. If connected the box and channel information will display. Click "Setup" > "Calibration Mode", select "Manual".

2. Select the channel to calibrate (1#: I--, V--,I2--).
3. Select current or voltage to calibrate.
4. Parameters setup. Press "Setup" and select "Calibration Setup".




Figure 5-4

For both current calibration and voltage calibration, two reference points are needed. Generally one point is chosen between 10%~20% and the other between 70%~90%. The two points should not be too close or near the maximum.

For voltage calibration a resistance is used. The value of the resistance can be obtained by click "Prompt resistance Range"

5. Click "Advanced" and press "Read". The values of k1 and k2 should be very close to 2097152. If either is 20% higher or less than that value, Press "Init-Value" and Write.
6. Start Calibration.

Change the Box No. of the device

In the Advanced setup of the LANDCali, the Box No. can be revised. If you received two devices with the same Box No, one has to change the Box No. The Current and Voltage Ranges are determined during the manufacturing and are not supposed to be changed.

First open the device which needs to change the Box No., but other devices need close and our software need exit. Then open the LANDCali.exe software, find "Unit From" and press "Connect" (see Figure 5-5), When test result is coming out, press "Advanced" (see Figure 5-6), then the Box No. Of the device can be changed. Once the Box No. is changed, please press "Write"(see Figure 5-6).




Figure 5-5




Figure5-6

Notes: The Current and Voltage Ranges are determined during the manufacturing and are not supposed to be changed.